

# INSTALLATION INSTRUCTIONS

## YOUR SHIPMENT INCLUDES:

1. Roller Track
2. Wall Mount Supports
3. Hinged trolley hangers
4. Face Plate Clamp Brackets
5. 20 1/4" Kep Nuts
6. 20 1/4" Hex Nuts
7. 20 1/4" Socket Head Cap Screws
8. End Stop

## TOOLS REQUIRED:

1. Ladder
2. Electric Drill w/1/2" Bit
3. 7/16" Socket Wrench and 5/32" Allen Wrench
4. Utility Knife or Scissors

## INSTRUCTIONS FOR MOVING TRACK INSTALLATION:

1. Install track level by slipping wall mount supports over each section of track. **See Figure 1.** Using track and supports as templates, mark holes with pencil. Drill mounting holes.
2. Mount track to wall beginning in the center.
3. Link hinged trolley hangers together and slide them into track. **See Figure 2.**
4. Install track end stops with socket head cap screws and hex nuts. **See Figure 3.**
5. Hang vinyl strips from studs. Secure them with face plate clamp brackets (flanges facing out) and kep nuts. **See Figure 4.**
6. If the total width of all strips attached is wider than the track, trim the last strip to fit or increase overlap distance.
7. Trim strips to clear floor by approximately 1/8".

**CLEANING:** Your TUF-FLEX MATERIAL is easily cleaned by using a towel or soft brush and a 10% solution of dishwashing liquid soap and water. Rinse with clean water. Cleaning will also create an antistatic effect.



Manufacturing, Inc.

350-B Fischer Avenue, Costa Mesa, CA 92626

(714)662-3539 • FAX (714)662-0901

1-800-722-FLEX(3539)

