

HARDWARE INCLUDED

- (a.) Upper Mounting Bracket (2 ea.)
- (b.) Lower Riser (2 ea.)
- (c.) Cover Plates (2 ea.)
- (d.) Anchor Bolts (14 ea.)
- (e.) Self Locking Nuts (4 ea.)

INSTALLATION TOOLS (NOT INCLUDED)

- 3/16 Wrench
- Wooden Wedge



Step One

Disassemble the **UPPER MOUNTING BRACKET** by removing the two bearings with a 3/16 hex wrench.

Install the **UPPER MOUNTING BRACKET** with Anchor bolts (8ea) to the center of door jamb and header.

Reassemble the **UPPER MOUNTING BRACKET**

NOTE: Bearings must be tight. Do not reassemble the Self Locking Nuts (4ea) at this time.

Step Two

Install the **LOWER RISER** with Anchor bolts (6ea) to the door jamb & floor.

NOTE: The center of the **LOWER RISER** must be plumb to the center of the **UPPER MOUNTING BRACKET**.

Step Three

Tilt **DOOR PANEL** and insert **LOWER POST** into **LOWER RISER**.

Step Four

Align **DOOR PANEL** with the 4 mounting studs on the **UPPER MOUNTING BRACKET** and lightly tighten the Self Locking Nuts (4ea).

NOTE: Insert **WOODEN WEDGE** under **The DOOR PANEL** to assist with installation.

Step Five

Remove **WOODEN WEDGE**. Adjust **DOOR PANEL** to center by rotating **DOOR PANEL** on **UPPER MOUNTING BRACKET**. Securely tighten the 4 Self Locking Nuts. Check **DOOR** for proper closure.

NOTE: Insert **WOODEN WEDGE** under **The DOOR PANEL** to assist with installation.

Step Six

Install the **COVER PLATES** (2ea). Remove protective film from **COVER PLATES** (2ea).