


**HARDWARE INCLUDED**

- (a.) Lower Riser (2 ea.)
- (b.) Upper bushing housing (2 ea.)
- (c.) Adjustable cams (2 ea.)
- (d.) 1/4-20x3/4" bolts (4 ea.)
- (e.) 1/4" Washers (4 ea.)
- Piece nylon webbing (1 ea.)



**Step 1:** Install upper bushing housing flush (a) to header and centered in door jamb.  
Install Lower riser (b) on floor and plumb to upper bushing housing.

Note: Installer to use typical standard anchors suitable for building construction.



**Step 2:** Lay out Nylon with door panel on floor.



**Step 3:** Align hinge tube (c) with lower riser bushing.



**Step 4:** Lift door using nylon webbing.

Note: This is a two person job.



**USE CAUTION:**  
Risk of pinching fingers between door edge and door jamb.



Insert Lower hinge tube into riser.

**Step 5:** a. Lift Door straight up, insert upper hinge tube into upper bushing housing. b. Cam Follower will pass through the slot in the upper bushing housing. c. Rotate Door 90 Degrees; door will now hang by itself.



5a.



5b.



5c.

**Step 6:** Install Weatherstrip.



**Step 7:** Lift Door and insert block of wood above lower riser as shown.



**Step 8:** Install adjustable cam using 1/4"-20x3/4" bolts.  
Remove wood block, Door will return to center.



**Step 9:** Center Door in Door jamb by rotating adjustable cam.  
Tighten bolts.

